

The bliss 1 and bliss 3 MINI VIBES infuse classical architecture of design with the spirit of sensory pleasures. Special features of these mini vibes include:

- unique textural forms
- 9 vibration modes
- whisper quiet technology™
- one touch operation
- 100% Pure Silicone Body



ON/OFF Button

- Press and hold for 1 second to turn on.
- Press ON/OFF button to cycle through the 9 vibration modes.
- Press and hold for 5 seconds to turn off.

Silicone Body

- Lay flat for strong vibrations

Silicone Tip

- Use tip for soft vibrations

Battery House

- Twist hard plastic base counter clockwise to open.
- Requires 2 x AAA batteries.




Using your bliss MINI VIBE

Insert 2 x AAA batteries into the battery house.
 See +/- diagram on internal casing for correct placement.
 Replace hard plastic base and press ON/OFF button to test.

Other Tips:
 -Always use fully charged re-chargeable batteries or new batteries.

Vibration mode guide



One (1) Year Limited Warranty.
 Leather protective pouch and batteries included.

To ensure the longevity of your bliss MINI VIBE please follow these simple guidelines:

Cleaning

Always clean your BLISS mini vibe thoroughly before and after each use. Wash the silicone body with warm water and antibacterial soap. Rinse with clean hot water and pat dry immediately with a lint-free cloth. Avoid submerging or getting water on or in the hard plastic base or around the ON/OFF button.
 Never use massage oil, cream, lubricants or cleaners that contain alcohol, petrol or acetone.
 Never use an abrasive brush or cleanser to clean the silicone body.

Storage

Place your BLISS mini vibe in the protective leather pouch for best storage. Store in a dry, dust-free place and away from toys made from other materials. Avoid leaving your vibe in direct sunlight and never expose to extreme heat. Remove batteries after use and store separately.

*Tip –pouch ideal for safe and discreet storage when traveling.

Safety

To ensure the longevity of this product please read the user manual in full before use. Do not discard these instructions. OPHORIA™ fine bedroom toys have been carefully engineered for both performance and safety.

Please follow basic safety precautions including the following:


- Do not place product base into or store in water or liquid.
- Do not insert batteries into housing if damp or wet.
- Do not insert batteries if any corrosion present.
- Do not use product if it is not working correctly.
- Do not use if vibrating motor or outer silicone sleeve has been damaged.
- Do not dispose of either the product or batteries in a fire.
- Do not use in conjunction with other products unless recommended by OPHORIA™.
- Do not leave unattended on any surface while it is operating.
- Do not use product on swollen or inflamed areas or broken skin.
- Do not use on sensitive skin areas or areas of poor circulation.
- Do not use for treatment of muscle pain or as a substitute for medical attention.
- Not recommended for use while pregnant.
- Do not use product when sleeping.

If you have concerns regarding your health, consult your doctor before using this product.


OPHORIA™ products are intended for adults only. Use product(s) at your own risk. OPHORIA™ assumes no responsibility or liability for the use or misuse of this product.

Product may be changed for improvements without notice.

Product Specifications



FRONT



BACK